

## PC Laptop (HDMI)


To sign out an HDMI cable visit the IMS Classroom Technology Support office in Loeb D283. Once you have the HDMI cable you will be able to connect it to your laptop and the classroom projector(s) by using the HDMI port located inside the teaching console.

### STEP 1

Connect one end of the HDMI cable to the port inside the equipment cabinet (labeled HDMI), and connect the other end of the HDMI cable to your laptop.




### STEP 2




In **single** projection rooms with a keypad, select "HDMI".

## Laptop Control



In **single** projection rooms with a touch panel, select "Laptop" then "HDMI"



In **dual** projection rooms, select “Computer” or “Laptop”, then “HDMI”



**Note:** You may need to toggle the video output of your laptop before an image displays on an external device like a projector. On a Windows-based laptop, a quick way to do this is to press the Windows button plus the letter P.

- Acer      Fn + F5
- Apple    Fn + F7
- Compaq   Fn + F4
- Dell      Fn + F8
- Fujitsu   Fn + 10
- HP        Fn + F4
- IBM      Fn + F7
- Panasonic Fn + F3
- Toshiba   Fn + F5

You can also use this list of function (Fn) keys to toggle the video output on the most common manufacturers of laptops.